



HOT DISPLAY UNIT

CONTENTS

A	GENERAL INFORMATION.....	Page 2
A1	PRODUCT DESCRIPTION	Page 3
A2	TECHNICAL INFORMATION	Page 3
A3	TRANSPORTATION.....	Page 4
A4	UNPACKING	Page 4
B	INSTALLATION	Page 4
C	SAFETY INSTRUCTIONS.....	Page 5
D	OPERATION	Page 6
E	CLEANING & MAINTENANCE	Page 7
F	TROUBLESHOOTING.....	Page 8
G	SPARE PART LIST- EXPLODING DRAWING	Page 9
H	ELECTRIC CIRCUIT SCHEMA.....	Page 11

A GENERAL INFORMATION

Before installing the appliance, read operation and maintenance instructions carefully. Wrong installation and part changing may damage the product or may cause injury on people. These are not in our company's responsibility to damage the appliance intentionally, negligence, detriments because of disobeying instructions and regulations, wrong connections. Unauthorized intervention to appliance invalidates the warranty.

1. This instruction manual should be kept in a safe place for future reference.
2. **Installation should be made in accordance with ordinances and security rules of that country by a qualified service personnel.**
3. This appliance has to be used by trained person.
4. Please turn off the appliance immediately in the event of malfunction or failure. The appliance should be repaired only by authorized service personnel. Please demand original spare part.

HOT DISPLAY UNIT

A1 PRODUCT DESCRIPTION

*The Professional Hot display unit, that provides high efficiency has been designed to be used in industrial kitchens.

Product Code	Dimensions (mm)	Weight (kg)	Packaging Dimensions (mm)
EMP.STU.01	725x570x562	19	800X810X240
EMP.STU.02	1040x570x565	27	1080X930X200

A2 TECHNICAL INFORMATION

Code	Capacity (GN)	Power (KW)	Operating Voltage (V)	Cable (mm ²)	UV Lamp (W)
EMP.STU.01	2x1/1	1,3	220	3x1,5	150X2
EMP.STU.02	3x1/1	1,9	220	3x1,5	150X3

A3 TRANSPORTATION

*This appliance can be moved by hand from area to area. Do not crash and drop the appliance while transporting.

A4 OPENING THE PACKAGE

*Please unpack the package according to the security codes and ordinances of current country and get rid from the pack. Parts which contacts with food are produced by stainless steel. All plastic parts are marked by material's symbol.

*Please check that all the parts of appliance had come completely and if they are damaged or not during the shipping.

B INSTALLATION

*Please place the product to straight and sturdy ground, please take necessary steps against possibility of overturn.

*Technician who will serve for installation and service for the appliance must be professional on this subject and must have installation and service licenses by the company.

*Connection to Electric Power Supply must be done by authorized person.

*Please be sure that the voltage connected to appliance must be equal with the voltage which is on appliance's label.











This appliance must be connected to an earthed outlet in accordance with safety rules and standards.

*Appliance's earthing must be connected to earthing line on panel which is nearest to electric installation.

*Connection to the main fuse and leak current fuse must be done in accordance with the current regulations.

HOT DISPLAY UNIT

C SAFETY INSTRUCTIONS

-  *Do not use the appliance in insufficient lighted place.
-  *Do not touch the moving attachments while the appliance operates.
-  *Do not install the appliance in the presence of flammable or explosive materials.
-  *Do not operate the appliance when the machine is empty.
-  *Do not load so less or more than appliance's capacity.
-  *Do not attempt to use the appliance without suitable protective equipments.
-  *Because of any reason if there is a fire or flame flare where the appliance is used, turn off all gas valves and electric contactor switch quickly and use fire extinguisher. Never use water to extinguish the fire.
-  *All the damages because of not having earthing connection will not be on warranty.

D OPERATION

*Control Panel:



- A : "ON" position
- B : "OFF" position
- C : Thermostat button
- D : Indicator lamp

Operating:

- Plug in the appliance.
- In order to operate the appliance switch to (ON) position.
- When the appliance's lamp is working , please check the light in the bottom side of it if it's working also .
- Adjust the thermostat heat to desired temperature.
- The product which you want to heat it , please put it on the glass part of the machine .
- The appliance can keep heating the food to the time you want to take it .
- After heating process,switch to (OFF) position and unplug the appliance.

HOT DISPLAY UNIT

E CLEANING & MAINTENANCE

➤ **CLEANING AND MAINTENANCE AFTER EVERY USE;**

- Always turn off the appliance and disconnect from the power supply before cleaning.
- The parts that contact with food must be cleaned after every use.
- Clean the outer surface and lid of the appliance with moist cloth.
- Do not use abrasive cleaning chemicals as these can leave harmful residues.
- Do not wash the appliance with water during the cleaning.

➤ **PERIODIC CLEANING AND MAINTENANCE;**

- Maintenance should be done by qualified person.
- Get the periodic maintenance of the appliance once in every 15 days.
- Check the resistances in periodic times and make their maintenance.
- Check the UV lamp in periodic times.
- Check the appliance's mica parts in periodic time. Scar crevice and broken parts must be changed.

F TROUBLESHOOTING**THE APPLIANCE DOESN'T OPERATE**

1. Check if the appliance is plugged in.
2. Check the electrical connections and voltage.
3. Check if the fuse is on or off.

THE APPLIANCE DOESN'T HEAT WELL

1. Check the thermostat button and heat setting.
2. Check the resistance.
3. Check the lamp.


THE APPLIANCE STOPPED

1. The appliance can stop due to low voltage. In this situation check the voltage.

- If keeping the hot is not done at suitable quality
- If any function of security doesn't work
 - Do not use the appliance.

***If these problems are still going on, contact with our authorized services.**


HOT DISPLAY UNIT



G SPARE PART LIST-EXPLODING DRAWING

NO	ÜRÜN ADI	ÜRÜN KODU
1	228MM*672MM*3 MM TWISTED BLACK PLEXY	M.CAM-MKA-005
2	E-27 PORCELAIN CASE	M.ELK-LMB-DUY-002
3	GENERAL/OSRAM 150W BR125 INFARED BULB	M.ELK-LMB-ARM-007
4	CHASSIS	-
5	R1043 230V 2*500W 660*520*8MM HOT GLASS TWO	M.ELK-RZS-CAM-001
6	SOCKET WARNING LAMP - GREEN	M.ELK-LMB-SNY-001
7	30-90 THERMOSTAT	M.ELK-MEK-TRM1-003
8	THERMOSTAT BUTTON	M.AKS-DGM-MUH-001
9	ILLUMINATED SQUARE SWITCH-GREEN-10A-20V(CYBER)	M.ELK-SLT-ANL-002
10	M10*35 RUBBER FOOT (STOVE TOP DEVICE)	M.AKS-AYK-PLS-002


G YEDEK PARÇA LİSTESİ-DEMONTE GÖRÜNÜŞÜ



NO	ÜRÜN ADI	ÜRÜN KODU
1	228MM*987MM*3 MM TWISTED BLACK PLEXY	M.CAM-MKA-004
2	E-27 PORCELAIN CASE	M.ELK-LMB-DUY-002
3	GENERAL/OSRAM 150W BR125 INFARED BULB	M.ELK-LMB-ARM-007
4	CHASSIS	-
5	R1043 230V 2*500W 660*520*8MM HOT GLASS TWO	M.ELK-RZS-CAM-002
6	SOCKET WARNING LAMP - GREEN	M.ELK-LMB-SNY-001
7	30-90 THERMOSTAT	M.ELK-MEK-TRM1-003
8	THERMOSTAT BUTTON	M.AKS-DGM-MUH-001
9	ILLUMINATED SQUARE SWITCH-GREEN-10A-20V(CYBER)	M.ELK-SLT-ANL-002
10	M10*35 RUBBER FOOT (STOVE TOP DEVICE)	M.AKS-AYK-PLS-002

HOT DISPLAY UNIT


H ELECTRIC CIRCUIT SCHEMA



EMP.STU.01

A1-A2	T1-T2	R1-R2	L1-L2	L3-L4
LARGE LIGHTED 0-1 SWITCH	THERMOSTAT 30-90°C	RESISTANCE 500W	UV LAMP 150W	THERMOSTAT OPEN INDICATOR LAMP

H ELECTRIC CIRCUIT SCHEMA



EMP.STU.02

A1-A2-A3	T1-T2-T3	R1-R2-R3	L1-L2-L3	L4-L5-L6
LARGE LIGHTED 0-1 SWITCH	THERMOSTAT 30-90°C	RESISTANCE 500W	UV LAMP 150W	THERMOSTAT OPEN INDICATOR LAMP



HOT DISPLAY UNIT